



Butyl Mastic Primer

C-Tech Rubber Butyl Mastic Primer is used for the priming of concrete surfaces before the laying of butyl mastic tapes.

C-Tech Rubber Butyl Mastic Primer:

- Fills surface voids and imperfections
- Encourages excellent adhesion of tape to surfaces
- High penetration of porous surfaces
- Dries quickly

How to Apply

1. Thoroughly stir primer prior to use
2. Brush down sealing surfaces to remove any foreign or loose material.
3. Apply with a brush onto clean, dry surface in a thin even coat.
4. Allow to dry at ambient until primer is tack dry, before applying butyl tape.

Storage

Store below 28° C out of direct sunlight.
Replace lid when not in use.

Safety Directions

Highly flammable. Do not use near spark producing tools. Take precautionary measures against static charges. Keep away from heat, flame and other ignition sources. Avoid contact with skin and eyes and avoid breathing vapours. Do not swallow. Wear protective gloves, glasses and clothing when using. If clothing becomes contaminated remove and wash before re-use. Use in a well ventilated area.

First Aid

If poisoning occurs, contact doctor or Poisons Information Centre on 131126 (Aus)
If swallowed, do not induce vomiting, give a glass of water.



C-Tech Rubber USA LLC

7206 Peppermill Parkway Phone: 843 552 4496
North Charleston SC 29418 Fax: 843 552 0040
USA Cell: 843 822 0664

Email: stevesuttie@homesc.com

C-Tech Rubber Pty Ltd

17 Devon Road Ph: 61 2 9829 3022
Ingleburn NSW 2565 Fax: 61 2 9829 4085
Australia

Email: sales@ctech-rubber.com.au

